



Einhell

EXPERT

DRAFT

POWER X-CHANGE

Cordless Lawn Trimmer

GE-CT 18/33 Li E-Solo

Item No.: 3411270

Ident No.: 21012

Bar Code: 4006825671186

The Einhell Cordless Lawn Trimmer GE-CT 18/33 Li E-Solo is perfect for keeping the edges of lawns and hard-to-reach areas of your garden neat. The powerful motor drives a spool holding a 8 m-long and 2 mm-thick filament line. The trimmer offers maximum comfort and control thanks to its lightweight aluminium handle pole, auxiliary handle and carrying strap. The cutting head is perfectly angled to achieve the best cutting results, while the two-speed selector ensures the tool can be adapted to the job in hand. The lawn trimmer's Flowerguard protects other plants, while a sturdy steel frame protects the installed battery. Battery and charger available separately.

Features & Benefits

- Member of the Power X-Change family, 1x 18 V battery required
- Optimum cutting results due to powerful thread technology
- Speed control for controlled cuts
- Individually adjustable additional handle for two-handed guidance
- Lightweight and separable aluminium guide bar
- Flowerguard protects other plants
- Carrying strap for back-friendly work
- Thread spool with automatic jog for fast thread tracking
- Steel frame for effective battery protection
- Supplied without battery and charger (sold separately)

Technical Data

- | | |
|---------------------------|----------------|
| - Cutting feature | Single line |
| - Thread length | 800 cm |
| - Cutting width of thread | 33 cm |
| - Readjustment of thread | Tipp automatic |
| - Thread diameter | 2 mm |

Logistic Data

- | | |
|---------------------------------|--------------------|
| - Product weight | 2.75 kg |
| - Gross weight single packaging | 4 kg |
| - Dimensions single packaging | 265 x 130 x 875 mm |
| - Pieces per export carton | 3 Pieces |
| - Gross weight export carton | 15 kg |
| - Dimensions export carton | 900 x 410 x 285 mm |



BATTERY & CHARGER
NOT INCLUDED



ERGONOMIC



ELECTRONIC SPEED CONTROL



INCL. CARRYING BELT



BATTERY PROTECTOR




1x 18V BATTERY POWERED (NOT INCLUDED)



BATTERY & CHARGER
NOT INCLUDED



18 V



ELECTRONIC SPEED CONTROL



SPLIT SHAFT EASY TRANSPORT

Available as special accessories



Line spool f. GE-CT 36/30 Li E
Lawn Trimmer Accessory
Item No.: 3405096
Bar Code: 4006825632767
Einhell Accessory



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



18V 4,0Ah Power X-Change 1
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



PXC Akku-Wandhalterung
PXC-Battery Accessory
Item No.: 4514155
Bar Code: 4006825658774
Einhell Accessory



18V 4,0Ah Power-X-Change Plus
Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory



18V 3,0 Ah Power-X-Change 2
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



18V 5,2Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



18V 4-6Ah Multi-Ah PXC Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210
Einhell Accessory



18V 2,0Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



18V 4,0Ah PXC Starter Kit 1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



18V 2,5Ah Power X-Change
Battery
Item No.: 4511516
Bar Code: 4006825650518
Einhell Accessory



2x 5,2Ah & Twincharger Kit
PXC-Starter-Kit
Item No.: 4512108
Bar Code: 4006825652376
Einhell Accessory



18V Battery Charger 3,0A - PXC
Charger
Item No.: 4514095
Bar Code: 4006825655292
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1
PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory



5,2Ah & 4A Fastcharger
PXC-Starter-Kit
Item No.: 4512114
Bar Code: 4006825656787
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB 1
Battery
Item No.: 4511489
Bar Code: 4006825638578
Einhell Accessory



Power X-Boostcharger 6A
Charger
Item No.: 4512064
Bar Code: 4006825629019
Einhell Accessory



18V 5-8Ah Multi-Ah PXC Plus
Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory



18V 3,0Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory

Battery-Running-Times



One Battery for All

trimming¹
(min.)

1.5 Ah	15
2.0 Ah	20
2.5 Ah	25
3.0 Ah	30
4.0 Ah	40
5.2 Ah	50
6.0 Ah	60
8.0 Ah	80

Test setup:

1) lawn